



NOTES:

1. ALIGN WEBS OF ALL MEMBERS.
2. ATTACH PLYWOOD TO JOIST AT 12" O.C. IN FIELD OF BOARD AND 6" O.C. AT ENDS.

9 EXTERIOR WALL
LOAD BEARING WALL