



WW-D-0104 1 HR. VERTICAL TIE-IN TO CONCRETE SLAB

NOTES:

- 1.) SINGLE LAYER OF 5/8" TYPE X DRYWALL FOR 1 HOUR AND 2 LAYERS FOR 2 HOURS.
- 2.) ALWAYS CHECK UL FIRE RESISTANCE DIRECTORY FOR COMPLETE DESIGN REQUIREMENTS.
- 3.) ** IF THE IBC REQUIRES UL-2079 5TH EDITION, ADDITIONAL FILL MATERIAL MAY BE NEEDED IN THE DEFLECTION JOINT.