



WW-S-0057 STANDARD WALL VERTICAL WALL TIE-IN TO CONCRETE COLUMN

NOTES:

- 1.) SINGLE LAYER OF 5/8" TYPE X DRYWALL FOR 1 HOUR AND 2 LAYERS FOR 2 HOURS.
- 2.) ALWAYS CHECK UL FIRE RESISTANCE DIRECTORY FOR COMPLETE DESIGN REQUIREMENTS.