



SECTION A-A

**FRAMING NOTES:**

1. LATERAL BRACING OF WALL MAY NOT BE REQUIRED ON COMPOSITE WALLS. CHECK WITH LIMITING HEIGHT TABLES AND/OR DESIGN.
2. GYPSUM BOARD MUST BE APPLIED FULL HEIGHT IN THE VERTICAL ORIENTATION TO EACH STUD FLANGE AND INSTALLED USING MINIMUM #6 TYPE S DRYWALL SCREWS SPACED A MINIMUM OF 12" O.C. TO THE FRAMING MEMBERS.
3. ADDITIONAL ONE ROW OF LATERAL BRACING WILL BE REQUIRED IF USING DEEP LEG TOP TRACK OR YOU CAN USE SLOTTED TRACK TO ELIMINATE THE ADDITIONAL ROW OF LATERAL BRACING.

## COMPOSITE STUD WALL SECTION



**Design Group**

A Division of Ware Industries

100 Hendrick Dr., Suite 200, McDonough, GA 30253

TOLL FREE 1.866.545.1545 OR TECHNICALSERVICES@MARINOWARE.COM

The calculations and/or sketches contained herein are supplied solely to assist in the selection and/or analysis of Marino\WARE® products. The calculations and/or sketches are preliminary in nature and are not intended to replace the calculations and/or sketches and services of the Architect or Engineer of Record. Marino\WARE® in rendering such calculations and/or sketches shall in no way be deemed to assume any professional responsibility and hereby disclaims any and all such liability or obligation.