



#### FRAMING NOTES:

1. CT-STUDS TO BE CUT  $\frac{3}{4}$ " LESS THAN THE SPAN LENGTH BETWEEN THE TOP AND BOTTOM J-TABBED TRACKS AND MUST PUSH THE TABBED UP.
2. FACE LAYER OF GYPSUM BOARD MUST BE APPLIED IN THE HORIZONTAL ORIENTATION TO EACH STUD FLANGE AND INSTALLED USING MINIMUM #6 TYPE S DRYWALL SCREWS SPACED A MINIMUM OF 12" O.C. TO THE FRAMING MEMBERS. ADDITIONAL LAYER (IF REQUIRED) TO BE APPLIED VERTICALLY & OFFSET TO ENSURE THAT JOINTS WILL NOT ALIGN WITH INITIAL LAYER OF BOARD.
3. REFERENCE MARINO\WARE SHAFTWALL SYSTEM TECHNICAL CONTENT ON [www.MARINOWARE.com](http://www.MARINOWARE.com) FOR TYPICAL INSTALLATION PROCEDURES.

## SHAFTWALL FRAMING DETAIL



A Division of Ware Industries

100 Hendrick Dr., Suite 200, McDonough, GA 30253

TOLL FREE 1.866.545.1545 OR [TECHNICALSERVICES@MARINOWARE.COM](mailto:TECHNICALSERVICES@MARINOWARE.COM)

The calculations and/or sketches contained herein are supplied solely to assist in the selection and/or analysis of Marino\WARE® products. The calculations and/or sketches are preliminary in nature and are not intended to replace the calculations and/or sketches and services of the Architect or Engineer of Record. Marino\WARE® in rendering such calculations and/or sketches shall in no way be deemed to assume any preofessional responsibility and hereby disclaims any and all such liability or obligation.