




MarinoWARE® Fire Gasket® preformed firestop is composed of a vinyl frame with a bubble gasket and intumescent strip that is tested to UL 2079. It provides 1 hr and 2 hr firestop solutions in joints for both standard and shaft wall assemblies.



- ♥ Tested with up to 100% compression and 100% extension
- ♥ Remains flexible for life of the assembly
- ♥ Can be used in top-of-wall, bottom-of-wall, and vertical joints
- ♥ Can be installed to the track leg before or after attaching the track to the deck
- ♥ Installs fully cured, unaffected by water/moisture/temperature
- ♥ L-rating (smoke rating) of below 1 CFM
- ♥ For use in assemblies with STC Ratings up to 67
- ♥ No additional firestop sealant or spray required over metal deck mineral wool flute fillers
- ♥ Available in pink for use in concealed locations and black for exposed locations
- ♥ Paintable

Ordering / Packaging


| Description | Part # | Size | Length | Pcs/Ctn | Movement |
|--------------------------|--------|---------------|--------|---------|--------------|
| FIRE GASKET .5 (Pink) | FG.5 | 3/8" x 1-1/4" | 5' | 60 | 1/2" total |
| FIRE GASKET .5 (Black)* | FGB.5 | 3/8" x 1-1/4" | 5' | 60 | 1/2" total |
| FIRE GASKET 1 (Pink) | FG1 | 3/8" x 1-5/8" | 5' | 60 | 1" total |
| FIRE GASKET 1 (Black)* | FGB1 | 3/8" x 1-5/8" | 5' | 60 | 1" total |
| FIRE GASKET 1.5 (Pink) | FG1.5 | 3/8" x 2-1/4" | 5' | 50 | 1-1/2" total |
| FIRE GASKET 1.5 (Black)* | FGB1.5 | 3/8" x 2-1/4" | 5' | 50 | 1-1/2" total |


Storage / Warranty

- ♥ When stored indoors and kept dry in the original package, Fire Gasket will provide unlimited shelf life
- ♥ See Firestop Product Warranty for details

ASTM & Code Standards

- ♥ ASTM E-84
- ♥ ASTM E-1966
- ♥ UL 2079 5th Edition
- ♥ Cal State Fire (BML) 1451-2376:0004
- ♥ L-Rating (air leakage) testing for compliance with International Building Code (IBC) and Canadian Building Code (CBC)
- ♥ UL listings/approvals include: BW-S-0024; BW-S-0053; HW-D-0514, HW-D-0515; HW-D-0518; HW-D-0524; HW-D-0525; HW-D-0550; HW-D-0551; HW-D-0553; HW-D-0554; HW-D-0573; HW-D-0585; HS-D-0587; HW-D-0596; HW-D-0620; HW-D-0621; HW-D-0622; HW-D-0623; HW-D-0624; HW-D-0625; HW-D-0652; HW-D-0653; WW-D-0104; WW-S-0094
- ♥ U.S. Patent No. 10,246,871; 10,753,084; 10,954,670





Fire Gasket[®]

Fire Gasket[®] is the fastest firestopping solution for head-of-wall joints on the market, installing up to three times faster than traditional sealants and sprays. Fire Gasket[®] is installed pre-drywall, and is available in three different sizes to provide a range of unencumbered movement — 0.5", 1" and 1.5".

Installation Guide

Before Installation:

Install Fire Gasket[®] to the wall framing before hanging drywall.

Step 1:

Measure and cut to length.

Step 2:

Remove backing on adhesive foam tape.

Step 3:

Compress the bubble gasket firmly against the adjoining structure. Pressure the product into place while adhering it to the framing.

Step 4:

Install drywall directly over Fire Gasket[®] per the deflection requirement allowed by the required UL joint system reports.

Notes:

- To keep the drywall gap consistent, use an appropriately sized spacer on top of drywall.
- If desired, finish top of drywall with L Bead or Tear Away L Bead.
- Fire Gasket[®] can optionally be fastened to the framing using appropriate 1/2" screws through the adhesive foam on its lower leg.
- There should be no gaps left in joints between pieces. Additional sealant may be used at butt joint to ensure seamless joints.

Step 1:



Step 2:



Step 3:



Step 4:



Snipped Inside/Outside Corners:

Step 1:

Snip the small return leg at top/back just under the bubble gasket. Do not snip through the bubble gasket.

Step 2:

Snip 1/8" on the bottom of the Fire Gasket®.

Step 3:

Lightly score the intumescent and foam tapes with utility knife to keep it from ripping when bent. Do not cut all the way through the tapes.

Step 4:

Bend Fire Gasket® to meet the inside or outside corner and fasten into place with the foam tape and optionally with 1/2" framing screws through the lower adhesive area of the bead.

Step 1:




Step 2:



Step 3:



Step 4:



Snipped Horizontal to Vertical Joint:

Step 1:

Measure horizontal leg to length and snip off a flat 45° triangular section of the product.

Step 2:

Repeat with the vertical leg, and on install, ensure there are no gaps where the intumescent tape meets.

Step 1:



Step 2:



Mitered Horizontal to Vertical Joint:


Step 1:

Measure top leg to length. Lay product flat on miter saw and make appropriate 45° cut, ensuring product is oriented properly.

Step 2:

Repeat with vertical leg, and on install, ensure there are no gaps where the intumescent tape meets.

Step 1:



Step 2:



| Product | Movement | Standard Wall | Shaft Wall | Fluted Deck | Concrete Deck | Installation | Paintable | Sound Test |
|---|---|---------------|------------|-------------|---------------|------------------|-----------|------------|
| Fire Bead FIRE RATED DEFLECTION BEAD | 1/4" Comp Only | ✓ | ✓ | | ✓ | Post Drywall | ✓ | ✓ |
| Fire Gasket FIRESTOPPING FOR BUILDING JOINTS | FG .5: 1/2" Overall FG 1: 1" Overall FG 1.5: 1-1/2" Overall | ✓ | ✓ | ✓ | ✓ | Pre Drywall | ✓ | ✓ |
| HOTROD TYPE X FIRESTOPPING FOR BUILDING JOINTS | 1/2" Comp 1/4" Ext | ✓ | ✓ | ✓ | ✓ | Post/Pre Drywall | ✓ | ✓ |
| HOTROD XL FIRESTOPPING FOR BUILDING JOINTS | 1/2" Comp 1/4" Ext | ✓ | ✓ | ✓ | ✓ | Post Drywall | ✓ | ✓ |
| FireRip FIRESTOPPING FOR BUILDING JOINTS | FR2: 2" Overall FR3: 3" Overall | ✓ | ✓ | ✓ | ✓ | Post Drywall | ✓ | |
| FAS[®]-093X™ FAS[®]-093X™-V | 15% of 1/2" Joint Width | ✓ | ✓ | ✓ | ✓ | Post Drywall | ✓ | ✓ |

| Product | UL / Approvals (UL 2079 5th Edition) |
|---|---|
| Fire Bead FIRE RATED DEFLECTION BEAD | HW-D-0624; HW-D-0625; HW-D-0554; HW-D-0550; BW-S-0024; WW-D-0104 |
| Fire Gasket FIRESTOPPING FOR BUILDING JOINTS | HW-D-0515; HW-D-0514; HW-D-0524; HW-D-0551; HW-D-0550; HW-D-0554; HW-D-0600; HW-D-0620; HW-D-0652; HW-D-0518; HW-D-0553; HW-D-0573 ; HW-D-0623; WW-S-0057; BW-S-0024; WW-D-0104 |
| HOTROD TYPE X FIRESTOPPING FOR BUILDING JOINTS | HW-D-0624; HW-D-0625; HW-D-0554; HW-D-0550; BW-S-0024; WW-D-0104; WW-S-0057; HW-D-0514; HW-D-0518; HW-D-0524; HW-D-0652; HW-D-0620; HW-D-0573; HW-D-0525; HW-D-0553; HW-D-0621; WW-S-0094 |
| HOTROD XL FIRESTOPPING FOR BUILDING JOINTS | HW-D-0624; HW-D-0625; HW-D-0554; HW-D-0550; BW-S-0024; WW-D-0104, HW-D-0514; HW-D-0518; HW-D-0524; HW-D-0652; HW-D-0620; HW-D-0573; HW-D-0525; HW-D-0553; HW-D-0621; WW-S-0094 |
| FireRip FIRESTOPPING FOR BUILDING JOINTS | HW-D-0420; HW-D-0421; HW-D-1096; HW-D-0451; HW-D-0453; HW-D-0461; HW-D-0463; HW-D-0582; HW-D-0584; HW-D-0587; HW-D-0594; HW-D-0602; HW-D-0585 |
| FAS[®]-093X™ FAS[®]-093X™-V | HW-D-0596; HW-D-0621; WW-D-0172 |

YOUR SUCCESS DEPENDS ON QUALITY BUILDING PRODUCTS AND SO DOES OURS.

For over 30 years, Marino\WARE[®], a division of Ware Industries Inc., has served our customers with top quality cold-formed steel framing products, while delivering better solutions to design and construction challenges. We are committed to providing a superior customer experience through a vast selection of readily available products, a knowledgeable sales team, comprehensive technical support and services, prompt delivery through our fleet of trucks, and an extensive distribution network.

Our best-in-class product development team delivers innovative solutions to installation and cost challenges with products designed to save time, labor, and materials. In addition, we utilize the latest in roll forming techniques, maintain the latest level of technology available to the steel framing industry, and strictly adhere to all ASTM specifications.

Marino\WARE is 100% American-owned and operated. We take pride in creating local jobs, supporting local communities, and manufacturing products that reflect the uncompromising skill and ethics of our professional team. We operate state-of-the-art production facilities in New Jersey, Georgia, and Indiana, as well as a sales office in New York.

Visit MarinoWARE.com to experience our full line of innovative solutions.

For more information, please contact Marino\WARE[®] Technical Services at 866.545.1545

This technical information reflects the most current information available and supersedes any and all previous publications effective February 26, 2026 | MW Fire & Sound Installation Guide | © WARE Industries, Inc. 2026

Marino\WARE[®] operates state-of-the-art production facilities in New Jersey, Georgia, and Indiana, as well as a sales office in New York.

New Jersey Facility
400 Metuchen Road
South Plainfield, NJ 07080
800.627.4661
908.757.9000
Fax: 908.412.1442

Georgia Facility
777 Greenbelt Parkway
Griffin, GA 30223
800.504.8199
678.688.1312
Fax: 678.688.1379

Indiana Facility
4245 Railroad Avenue
East Chicago, IN 46312
866.636.6002
219.378.7100
Fax: 219.378.7106

New York Sales Office
51 John St. Ste. 1
Babylon, NY 11702
800.627.4667
631.691.2200
Fax: 631.691.1492

Marino\WARE[®] DesignGroup[™]
100 Hendrick Drive, Suite
200
McDonough, GA 30253
866.545.1545
678.688.7780
Fax: 770.507.2605